

KB[®] 15

KEYBOARD AMPLIFICATION SYSTEM

OPERATING GUIDE





Intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



Intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

CAUTION Risks of electrical shock — DO NOT OPEN

CAUTION To reduce the risk of electric shock, do not remove cover. No user serviceable parts inside. Refer Servicing to qualified service personnel.

WARNING To prevent electrical shock or fire hazard, do not expose this appliance to rain or moisture. Before using this appliance, read the operating guide for further warnings.



Este símbolo tiene el propósito de alertar al usuario de la presencia de instrucciones importantes sobre la operación y mantenimiento en la literatura que viene con el producto.



Este símbolo tiene el propósito de alertar al usuario de la presencia de “(voltaje) peligroso” que no tiene aislamiento dentro de la caja del producto que puede tener una magnitud suficiente como para constituir riesgo de corrientazo.

PRECAUCION Riesgo de corrientazo - No abra.

PRECAUCION Para disminuir el riesgo de corrientazo, no abra la cubierta. No hay piezas adentro que el usuario pueda reparar. Deje todo mantenimiento a los técnicos calificados.

ADVERTENCIA Para evitar corrientazos o peligro de incendio, no deje expuesto a la lluvia o humedad este aparato. Antes de usar este aparato, lea más advertencias en la guía de operación.



Ce symbole est utilisé pour indiquer à l'utilisateur qu'il ou qu'elle trouvera d'importantes instructions sur l'utilisation et l'entretien (service) de l'appareil dans la littérature accompagnant le produit.



Ce symbole est utilisé pour indiquer à l'utilisateur la présence à l'intérieur de ce produit de tension non-isolée dangereuse pouvant être d'intensité suffisante pour constituer un risque de choc électrique.

ATTENTION Risques de choc électrique — NE PAS OUVRIR!

ATTENTION Afin de réduire le risque de choc électrique, ne pas enlever le couvercle. Il ne se trouve à l'intérieur aucune pièce pouvant être réparée par l'utilisateur. Confier l'entretien à un personnel qualifié.

AVERTISSEMENT Afin de prévenir les risques de décharge électrique ou de feu, n'exposez pas cet appareil à la pluie ou à l'humidité. Avant d'utiliser cet appareil, lisez les avertissements supplémentaires situés dans le guide d'utilisation.



Dieses Symbol soll den Benutzer auf wichtige Instruktionen in der Bedienungsanleitung aufmerksam machen, die Handhabung und Wartung des Produkts betreffen.




Dieses Symbol soll den Anwender vor unisolierten gefährlichen Spannungen innerhalb des Gehäuses warnen, die von Ausreichender Stärke sind, um einen elektrischen Schlag verursachen zu können.

VORSICHT Risiko - Elektrischer Schlag! Nicht öffnen!

VORSICHT Um das Risiko eines elektrischen Schlages zu vermeiden, nicht die Abdeckung entfernen. Es befinden sich keine Teile darin, die vom Anwender repariert werden könnten. Reparaturen nur von qualifiziertem Fachpersonal durchführen lassen.

ACHTUNG Um einen elektrischen Schlag oder Feuergefahr zu vermeiden, sollte dieses Gerät nicht dem Regen oder Feuchtigkeit ausgesetzt werden. Vor Inbetriebnahme unbedingt die Bedienungsanleitung lesen.

ENGLISH



CHANNEL 1 INPUT (1)

Signal input for channel one. This input will accept signals from most electronic keyboards.

GAIN (2)

Controls the channel volume.

CHANNEL 2 INPUT (3)

Signal input for channel two. This input will accept signals from most electronic keyboards.

GAIN (4)

Controls the channel volume.

LOW FREQUENCY EQ (5)

An active tone control (shelving type, ± 15 dB) that varies the low frequency range.

CAUTION: Excessive low frequency boost causes greater power consumption and increases possibility of speaker damage.

MID EQ (6)

An active tone control (peak/notch, ± 15 dB) that adjusts the mid frequency range.

HIGH FREQUENCY EQ (7)

An active tone control (shelving type, ± 15 dB) that varies the high frequency range.

HEADPHONE OUT (8)

This stereo jack allows the signal to flow to both sides of any stereo headset. When headphones are connected to the amplifier, the internal speaker is automatically turned off.


NOTE: The headphone system will not work with headsets equipped with a mono phone plug.

POWER LED (9)

Illuminates when AC power is being supplied to the unit.

POWER SWITCH (10)

Depress the switch to the "On" position. The red pilot light (LED) will illuminate indicating power is being supplied to the unit.



12

11

RECORD OUT (11)

1/4" jacks are provided for recording directly from the main signal. The signal at this point is divided into dual output (left and right).

LINE CORD (120V PRODUCTS ONLY) (12)



For your safety, we have incorporated a 3-wire (mains) cable with proper grounding facilities. It is not advisable to remove the ground pin under any circumstances. If it is necessary to use the equipment without proper grounding facilities, suitable grounding adaptors should be used. Less noise and greatly reduce shock hazard exists when the unit is operated with the proper grounded receptacles.

SPECIFICATIONS

Rated Power & Load

12 W RMS into 3.2 ohms

Power @ Clipping (Typically)

(10% THD, 1 kHz, 120 V AC line) 12 W RMS into 3.2 ohms

Total Harmonic Distortion

Less than 0.5%, 100 mW to 75 W RMS, 60 Hz to 10 kHz, 3.2 ohms
(Typically below 0.2%)

Power Consumption

30 watts, 50/60 Hz, 120 V AC

PREAMP SECTION

The following specs are measured @ 1 kHz with the master EQ flat @ 0 dB.
Nominal values are with levels @ 5
Minimum values are with levels @ 10

Instrument Inputs

Input impedance: 47 K ohms
Nominal input level: -14 dBV, 200 mV RMS
Minimum input level: -26 dBV, 50 mV RMS
Maximum input level: Unlimited

Record Output (RCA Jacks)

Load impedance: 10 K ohms or greater
Nominal output level: -10 dBV, 0.3 V RMS (at 12 W RMS output level)
Maximum output level: +12 dBV, 5 V RMS

Headphone Output (Stereo phone jack, mono signal)

Load impedance: 4 ohms or greater

Nominal power output: 100 mW into 4 ohms
(Switching jack which disconnects the internal speaker when plug is inserted)

The following specs measured at nominal settings, all inputs terminated with 47 K ohms

Frequency Response

(Channel input/record output @ 0.3 V RMS level)
+0, -2 dB, 50 Hz to 20 kHz


Preamp Hum & Noise

-78 dBV (both channels operating)

Master Equalization

±15 dB @ 80 Hz & 8 kHz, shelving
±15 dB @ 800 Hz, peak/notch

BLOCK DIAGRAM



This block diagram shows signal flow within the unit. In order to thoroughly understand the unit's functions, please study the diagram carefully.

ESPAÑOL

Consulte los diagramas del panel delantero en la sección de inglés de este manual.

CHANNEL 1 INPUT (Entrada del canal 1) (1)

La entrada de señal para el canal 1. Esta entrada aceptará señales de la mayoría de los teclados electrónicos.

GAIN (Ganancia) (2)

Controla el volumen del canal.

CHANNEL 2 INPUT (Entrada del canal 2) (3)

La entrada de señal para el canal 2. Esta entrada aceptará señales de la mayoría de los teclados electrónicos.

GAIN (Ganancia) (4)

Controla el volumen del canal.

LOW EQ (Ecualizador de frecuencias graves) (5)

Un control de tono activo (tipo shelving, ± 15 dB) que varía la gama de frecuencias graves.

PRECAUCIÓN: Un impulso excesivo a las frecuencias graves produce mayor consumo de potencia y aumenta la posibilidad de dañar el altavoz.

MID EQ (Ecualización de frecuencias medias) (6)

Un control activo de tono (gradual ± 15 dB) que ajusta las frecuencias medias.

HIGH FREQUENCY EQ (Ecualizador de frecuencias agudas) (7)

Control de tono activo (tipo “repisa”, ± 15 dB) que varía la gama de frecuencias agudas.

HEADPHONE OUT (Salida para audífonos) (8)

Esta salida es un enchufe hembra estereofónico que permite usar audífonos comunes—escuchando la señal en ambos lados. Cuando se conectan los audífonos al amplificador, los altavoces internos son automáticamente desconectados.


NOTA: El sistema de audífonos no funcionará con audífonos equipados con una clavija monofónica.

POWER LED (LED indicador de corriente) (9)

Se ilumina cuando el equipo recibe la corriente alterna.

POWER SWITCH (Interruptor de corriente) (10)

Oprima el interruptor a la posición “hacia dentro” (encendido). La luz roja del piloto (indicador) se encenderá indicando que la unidad está recibiendo corriente alterna.



RECORD OUT (Salidas de grabación) (11)

Se suministra enchufes hembras “RCA” para grabar directamente desde la señal principal. La señal en este punto está dividida en una salida doble (izquierda y derecha).

LINE CORD (120 V PRODUCTS ONLY) (Cable de corriente para 120 v solamente) (12)

Para su protección hemos incorporado un cable de 3 polos con polo a tierra. No es recomendable remover la pata del polo a tierra bajo ninguna circunstancia, se recomienda un adaptador en caso necesario. Esto reducirá ruidos y peligrosos corrientazos.

F R A N C A I S

**Veillez vous référer au “front panel line art”
situé dans la section en langue anglaise de ce manuel.**

CHANNEL INPUT 1 (Entrée de canal 1) (1)

Entrée de signal pour le canal 1. Cette entrée peut recevoir les signaux de la plupart des claviers électroniques.

GAIN (2)

Contrôle le niveau de volume du canal.

CHANNEL 2 INPUT (Entrée de canal 2) (3)

Entrée de signal pour le canal 2. Cette entrée peut recevoir les signaux de la plupart des claviers électroniques.

GAIN (4)

Contrôle le niveau de volume du canal.

LOW FREQUENCY EQ (Égalisation grave) (5)

Réglage de tonalité actif (type passe-bas, ± 15 dB), affectant les fréquences de registre grave.

ATTENTION: Une forte accentuation des fréquences graves augmente la consommation de puissance et les risques de dommages au haut-parleur.

MID EQ (Égalisation moyennes) (6)

Réglage de tonalité actif (correction ± 15 dB) servant à ajuster les fréquences de registre moyen.

HIGH FREQUENCY EQ (Commande d'égalisation des fréquences aiguës) (7)

Réglage de tonalité actif (type passe-haut, ± 15 dB) contrôlant les fréquences de registre aigu.

HEADPHONE OUT (Sortie pour casque d'écoute) (8)

Cette prise jack stéréo accepte n'importe quel casque d'écoute stéréo et y envoie le signal sur les deux cotés. Lorsqu'un casque est branché à l'amplificateur, le haut-parleur interne est automatiquement mis hors-circuit.

NOTE: Le système de casque d'écoute ne fonctionne pas avec un casque équipé d'une fiche phono monophonique.

POWER LED (DEL témoin d'alimentation) (9)

S'allume quand l'unité reçoit l'alimentation CA.

POWER SWITCH (Interrupteur d'alimentation) (10)

Mettre l'interrupteur en position “On”. La lampe témoin rouge (DEL) s'illumine indiquant que l'appareil est alimenté en courant.



RECORD OUT (Sorties enregistrement) (11)

Prises jacks RCA permettant d'enregistrer directement à partir du signal principal. À ce point, le signal est divisé en deux sorties (gauche et droite).

LINE CORD (120V products only) (Cordon d'alimentation pour appareils 120V seulement) (12)

Pour votre sécurité, nous avons incorporé un câble d'alimentation secteur à 3 fils avec mise-à-terre appropriée. Il n'est pas recommandé d'enlever la broche de mise-à-terre en aucune circonstance. S'il est nécessaire d'utiliser l'équipement sans mise-à-terre appropriée, utilisez des adaptateurs de mise-à-terre convenables. Une bonne mise-à-terre amoindrit le bruit de fond et réduit grandement les risques de choc.

D E U T S C H

Siehe diagramm der frontplatte im englischen teil des handbuchs.

CHANNEL 1 INPUT (1)

Signal Eingang für Kanal Eins. Dieser Kanal verarbeitet die Signale der meisten elektronischen Keyboards.

GAIN (Gain) (2)

Regelt die Lautstärke des Kanals.

CHANNEL 2 INPUT (3)

Signal Eingang für Kanal Zwei. Dieser Kanal verarbeitet die Signale der meisten elektronischen Keyboards.

GAIN (Gain) (4)

Regelt die Lautstärke des Kanals.

LOW FREQUENCY EQ (5)

Aktive Klangregelung für die tiefen Frequenzen. Anhebung und Absenkung im Bereich von ± 15 dB möglich.

ACHTUNG: Extreme Bassanhebung erfordert einen höheren Leistungsbedarf und kann evtl. zu einer Lautsprecherbeschädigung führen.

MID EQ (Mitten-Klangregelung) (6)

Eine aktive Klangregelung mit Anhebung/Absenkung der Mittenfrequenzen um ± 15 dB.

HIGH FREQUENCY EQ (7)

Aktive Klangregelung für den hohen Frequenzbereich (± 15 dB).

HEADPHONE OUT (8)

Diese Stereobuchse leitet das Signal an beide Seiten eines jeden handelsüblichen Stereokopfhörers. Wenn ein Kopfhörer an den Verstärker angeschlossen wird, schaltet sich der Lautsprecher automatisch ab.

MERKE: Die Kopfhörerbuchse funktioniert nicht mit Kopfhörern, die mit einer Mono-Klinkenbuchse ausgestattet sind.

POWER LED (9)

Ist erleuchtet, wenn das Gerät eingeschaltet ist und mit Strom versorgt wird.

POWER SWITCH (Netzschalter) (10)

Bringen Sie den Schalter auf die ON-Position. Die rote Kontrollampe (LED) leuchtet und zeigt an, daß das Gerät eingeschaltet ist.



RECORD OUT (11)

Um direkt vom Hauptsignal aufnehmen zu können, sind hierfür Cinch-Buchsen vorgesehen. Das Signal wird hier in links und rechts gesplittet.

LINE CORD (120V products only) (Nur bei 120 Volt-Geräten) (12)

Zu Ihrer Sicherheit haben wir das Gerät mit einem dreiadrigen geerdeten Netzkabel versehen. Es ist unter keinen Umständen empfehlenswert den Erdungskontakt des Anschlußkabels zu lösen. Falls es notwendig sein sollte, das Equipment ohne die vorgesehene Erdung zu betreiben empfiehlt sich die Verwendung eines Grounding Adaptors. Die geringsten Störgeräusche und die höchste Sicherheit vor elektrischen Schlägen wird jedoch durch die Benutzung der vorgesehenen Erdungsmöglichkeiten erreicht.

THIS LIMITED WARRANTY VALID ONLY WHEN PURCHASED AND REGISTERED IN THE UNITED STATES OR CANADA. ALL EXPORTED PRODUCTS ARE SUBJECT TO WARRANTY AND SERVICES TO BE SPECIFIED AND PROVIDED BY THE AUTHORIZED DISTRIBUTOR FOR EACH COUNTRY.
Ces clauses de garantie ne sont valables qu'aux Etats-Unis et au Canada. Dans tous les autres pays, les clauses de garantie et de maintenance sont fixées par le distributeur national et assurées par lui selon la législation en vigueur.
Diese Garantie ist nur in den USA und Kanada gültig. Alle Export-Produkte sind der Garantie und dem Service des Importeurs des jeweiligen Landes unterworfen. Esta garantía es válida solamente cuando el producto es comprado en E.U. continentales o en Canada. Todos los productos que sean comprados en el extranjero, están sujetos a las garantías y servicio que cada distribuidor autorizado determine y ofrezca en los diferentes países.

**PEAVEY ONE-YEAR LIMITED
WARRANTY/REMEDY**

PEAVEY ELECTRONICS CORPORATION ("PEAVEY") warrants this product, EXCEPT for covers, footswitches, patchcords, tubes and meters, to be free from defects in material and workmanship for a period of one (1) year from date of purchase, PROVIDED, however, that this limited warranty is extended only to the original retail purchaser and is subject to the conditions, exclusions, and limitations hereinafter set forth:

PEAVEY 90-DAY LIMITED WARRANTY ON TUBES AND METERS

If this product contains tubes or meters, Peavey warrants the tubes or meters contained in the product to be free from defects in material and workmanship for a period of ninety (90) days from date of purchase; PROVIDED, however, that this limited warranty is extended only to the original retail purchaser and is also subject to the conditions, exclusions, and limitations hereinafter set forth.

CONDITIONS, EXCLUSIONS, AND LIMITATIONS OF LIMITED WARRANTIES

These limited warranties shall be void and of no effect, if:

- a. The first purchase of the product is for the purpose of resale; or
- b. The original retail purchase is not made from an AUTHORIZED PEAVEY DEALER; or
- c. The product has been damaged by accident or unreasonable use, neglect, improper service or maintenance, or other causes not arising out of defects in material or workmanship; or
- d. The serial number affixed to the product is altered, defaced, or removed.

In the event of a defect in material and/or workmanship covered by this limited warranty, Peavey will:

- a. In the case of tubes or meters, replace the defective component without charge.
- b. In other covered cases (i.e., cases involving anything other than covers, footswitches, patchcords, tubes or meters), repair the defect in material or workmanship or replace the product, at Peavey's option; and provided, however, that, in any case, all costs of shipping, if necessary, are paid by you, the purchaser.

THE WARRANTY REGISTRATION CARD SHOULD BE ACCURATELY COMPLETED AND MAILED TO AND RECEIVED BY PEAVEY WITHIN FOURTEEN (14) DAYS FROM THE DATE OF YOUR PURCHASE.

In order to obtain service under these warranties, you must:

- a. Bring the defective item to any PEAVEY AUTHORIZED DEALER or AUTHORIZED PEAVEY SERVICE CENTER and present therewith the ORIGINAL PROOF OF PURCHASE supplied to you by the AUTHORIZED PEAVEY DEALER in connection with your purchase from him of this product.
If the DEALER or SERVICE CENTER is unable to provide the necessary warranty service you will be directed to the nearest other PEAVEY AUTHORIZED DEALER or AUTHORIZED PEAVEY SERVICE CENTER which can provide such service.

OR

- b. Ship the defective item, prepaid, to:

PEAVEY ELECTRONICS CORPORATION
International Service Center
326 Hwy. 11 & 80 East
MERIDIAN, MS 39301

including therewith a complete, detailed description of the problem, together with a legible copy of the original PROOF OF PURCHASE and a complete return address. Upon Peavey's receipt of these items:

If the defect is remedial under these limited warranties and the other terms and conditions expressed herein have been complied with, Peavey will provide the necessary warranty service to repair or replace the product and will return it, FREIGHT COLLECT, to you, the purchaser.

Peavey's liability to the purchaser for damages from any cause whatsoever and regardless of the form of action, including negligence, is limited to the actual damages up to the greater of \$500.00 or an amount equal to the purchase price of the product that caused the damage or that is the subject of or is directly related to the cause of action. Such purchase price will be that in effect for the specific product when the cause of action arose. This limitation of liability will not apply to claims for personal injury or damage to real property or tangible personal property allegedly caused by Peavey's negligence. Peavey does not assume liability for personal injury or property damage arising out of or caused by a non-Peavey alteration or attachment, nor does Peavey assume any responsibility for damage to interconnected non-Peavey equipment that may result from the normal functioning and maintenance of the Peavey equipment.

UNDER NO CIRCUMSTANCES WILL PEAVEY BE LIABLE FOR ANY LOST PROFITS, LOST SAVINGS, ANY INCIDENTAL DAMAGES, OR ANY CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT, EVEN IF PEAVEY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

THESE LIMITED WARRANTIES ARE IN LIEU OF ANY AND ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR USE; PROVIDED, HOWEVER, THAT IF THE OTHER TERMS AND CONDITIONS NECESSARY TO THE EXISTENCE OF THE EXPRESSED, LIMITED WARRANTIES, AS HEREINABOVE STATED, HAVE BEEN COMPLIED WITH, IMPLIED WARRANTIES ARE NOT DISCLAIMED DURING THE APPLICABLE ONE-YEAR OR NINETY-DAY PERIOD FROM DATE OF PURCHASE OF THIS PRODUCT.

SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THESE LIMITED WARRANTIES GIVE YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE.

THESE LIMITED WARRANTIES ARE THE ONLY EXPRESSED WARRANTIES ON THIS PRODUCT, AND NO OTHER STATEMENT, REPRESENTATION, WARRANTY, OR AGREEMENT BY ANY PERSON SHALL BE VALID OR BINDING UPON PEAVEY.

In the event of any modification or disclaimer of expressed or implied warranties, or any limitation of remedies, contained herein conflicts with applicable law, then such modification, disclaimer or limitation, as the case may be, shall be deemed to be modified to the extent necessary to comply with such law.

Your remedies for breach of these warranties are limited to those remedies provided herein and Peavey Electronics Corporation gives this limited warranty only with respect to equipment purchased in the United States of America.

INSTRUCTIONS — WARRANTY REGISTRATION CARD

1. Mail the completed WARRANTY REGISTRATION CARD to:

PEAVEY ELECTRONICS CORPORATION
POST OFFICE BOX 2898
MERIDIAN, MISSISSIPPI 39302-2898

- a. Keep the PROOF OF PURCHASE. In the event warranty service is required during the warranty period, you will need this document. There will be no identification card issued by Peavey Electronics Corporation.
2. **IMPORTANCE OF WARRANTY REGISTRATION CARDS AND NOTIFICATION OF CHANGES OF ADDRESSES:**
 - a. Completion and mailing of WARRANTY REGISTRATION CARDS — Should notification become necessary for any condition that may require correction, the REGISTRATION CARD will help ensure that you are contacted and properly notified.
 - b. Notice of address changes — If you move from the address shown on the WARRANTY REGISTRATION CARD, you should notify Peavey of the change of address so as to facilitate your receipt of any bulletins or other forms of notification which may become necessary in connection with any condition that may require dissemination of information or correction.
3. You may contact Peavey directly by telephoning (601) 483-3365.

IMPORTANT SAFETY INSTRUCTIONS

WARNING When using electric products, basic cautions should always be followed, including the following.

1. Read all safety and operating instructions before using this product.
2. All safety and operating instructions should be retained for future reference.
3. Obey all cautions in the operating instructions and on the back of the unit.
4. All operating instructions should be followed.
5. This product should not be used near water, i.e., a bathtub, sink, swimming pool, wet basement, etc.
6. This product should be located so that its position does not interfere with its proper ventilation. It should not be placed flat against a wall or placed in a built-in enclosure that will impede the flow of cooling air.
7. This product should not be placed near a source of heat such as a stove, radiator, or another heat producing amplifier.
8. Connect only to a power supply of the type marked on the unit adjacent to the power supply cord.
9. Never break off the ground pin on the power supply cord. For more information on grounding, write for our free booklet "Shock Hazard and Grounding."
10. Power supply cords should always be handled carefully. Never walk or place equipment on power supply cords. Periodically check cords for cuts or signs of stress, especially at the plug and the point where the cord exits the unit.
11. The power supply cord should be unplugged when the unit is to be unused for long periods of time.
12. If this product is to be mounted in an equipment rack, rear support should be provided.
13. Metal parts can be cleaned with a damp rag. The vinyl covering used on some units can be cleaned with a damp rag, or an ammonia-based household cleaner if necessary. Disconnect unit from power supply before cleaning.
14. Care should be taken so that objects do not fall and liquids are not spilled into the unit through the ventilation holes or any other openings.
15. This unit should be checked by a qualified service technician if
 - a. The power supply cord or plug has been damaged.
 - b. Anything has fallen or been spilled into the unit.
 - c. The unit does not operate correctly.
 - d. The unit has been dropped or the enclosure damaged.
16. The user should not attempt to service this equipment. All service work should be done by a qualified service technician.
17. This product should be used only with a cart or stand that is recommended by Peavey Electronics.
18. Exposure to extremely high noise levels may cause a permanent hearing loss. Individuals vary considerably in susceptibility to noise induced hearing loss, but nearly everyone will lose some hearing if exposed to sufficiently intense noise for a sufficient time.

The U.S. Government's Occupational Safety and Health Administration (OSHA) has specified the following permissible noise level exposures

Duration Per Day In Hours	Sound Level dBA, Slow Response
8	90
6	92
4	95
3	97
2	100
1½	102
1	105
½	110
¼ or less	115

According to OSHA, any exposure in excess of the above permissible limits could result in some hearing loss.

Ear plugs or protectors in the ear canals or over the ears must be worn when operating this amplification system in order to prevent a permanent hearing loss if exposure is in excess of the limits as set forth above. To ensure against potentially dangerous exposure to high sound pressure levels, it is recommended that all persons exposed to equipment capable of producing high sound pressure levels such as this amplification system be protected by hearing protectors while this unit is in operation.

SAVE THESE INSTRUCTIONS



Features and specifications subject to change without notice.

Peavey Electronics Corporation 711 A Street / Meridian, MS 39301 / U.S.A. / (601) 483-5365 / Fax 486-1278
©1997 #80301248 Printed in U.S.A. 1/97